


PETKIT

PET GROOMING KIT

PETKIT AIRCLIPPER 5-IN-1

User Instruction



Please read the user instruction carefully prior to product use and keep it in a safe place


CONTENT

Product list	03
Product installation	05
Product use	06
Maintenance & cleaning	11
Basic specifications	14
A message to our valued customers	15
User safety guide	15


REMINDER

Before use:



- 1 Press the PUSH button on the front side of the dust cup



- 2 After the dust cup is lifted slightly, it can be removed.
- 3 Open the dust cup buckle and take out the functional parts



01 PRODUCT LIST




Functional parts




Electric clipper *1
(including body
fur trimmer)



Paw trimmer *1



Grooming brush*1



Deshedding brush*1



Crevice tool *1

Accessories



3mm



6mm



9mm




12mm


Electric clipper
comb attachments *4



Cotton filter *2




Hepa filter screen *2



Electric clipper TYPE-C
Charging cable *1



Soft hose *1




Storage bag *1

02 PRODUCT INSTALLATION


1. Dust cup installation

- ① Align the dust cup buckle with the main device slot
- ② Press the end of the dust cup until heard a "click" sound, which means the installation is successful



2. Soft hose installation


Align point **A** of the hose with the hose connector point **B**, after inserting screw it clockwise to the end to ensure that the point **C** is aligned with point **B**




* Gently pull the soft hose after installation, if it cannot be pulled out, which means it is installed in place.

3. Functional parts installation and removal (Following picture uses electric clippers as an example, and the installation method of other functional parts is the same)

- ① Functional part installation: Insert the hose connector into the functional part and fasten tightly
- ② Functional part removal: Press the button on the hose lightly to remove the functional part



4. Assembly completed




During use, the hose must not be folded or squeezed, otherwise it will affect normal usage.

03 PRODUCT USE

1. Turn on device and mode selection

- ❶ Insert power cable, press On/Off button to start the device




On/Off button
On/Off: short press



Suction switch button
Suction switch: short press

- ❷ 3 suction level to select



Level 1



Level 2



Level 3

* Note: The product has a voltage error protection setting, when the indicators flash at the same time, and there is a "drip" sound when pressing the button. Please check whether the power input voltage is wrong.

2. Electric clipper


Can be used for daily fur trimming, the body fur trimmer can shave body fur, and the Paw trimmer can shave paw fur and fur around the eyes.

*Note: Please be careful around the soft area of pet's skin, do not use excessive force to avoid skin scratches.

① Buttons and indicator light description


To avoid damage to the product, please use a power adapter with an output of DC 5V 1A for charging

* The electric clipper is equipped with over-charging voltage protection. When the charging voltage reaches 6V or above, the charging power supply will turn off, and blue and red indicator lights will flash alternately, indicating that the charging high-voltage protection function has been activated; at this time the device can not be charged, charging can resume again after replacing with the correct power adapter.





② Comb attachments use

When using comb attachments, please reserve a safe distance to effectively control the overall fur length.




* The reserved length is marked, allowing precise fur shaving.




⑤ Replacement of trimmer

Step 1: Turn the attachment counterclockwise to the end and take it out upwards.



Step 2: Vertically install the replacement attachment at an angle of 45°, and rotate it clockwise to the end.




⑥ Electric trimmer use instructions

***Note:** Remember to pay attention to the clipper edge and sharp position during use, and don't use excessive force to avoid skin scratches.



Body trimmer: Trims the overall fur length.
*For beginners, it is recommended to use it with comb attachments.




Paw trimmer: Trimming fur around feet, eyes and ears


2. Grooming brush

Can clean the remaining loose fur and dandruff on the pet's body, and also pulls the fur, making the fur more fluffy.


- 1 Press the HOLD button and push it forward to the end, then push the HOLD button downward to complete the locking before start use



- 2 Install the Grooming brush on the hose, turn on the device, and comb along the direction of pet fur



- 3 When the Grooming brush accumulates a certain amount of fur, push the HOLD button up to unlock the comb, and push it forward repeatedly until the fur is sucked into the dust cup




When the Grooming brush is not in use, it is recommended to adjust the HOLD button to the unlocked state for easy storage.

3. Deshedding brush

Can comb away remaining fur and dandruff, and can thin and unknot the fur.

- 1 Press the HOLD button and push it forward to the end, and then push the HOLD button downward to complete the locking before use




- 2 Install the Deshedding brush on the hose, turn on the device, and comb along the direction of pet fur

**Note: Please be careful on the soft area of the pet's skin, and don't use excessive force to avoid skin scratches.*




- 3 When the Deshedding brush accumulates a certain amount of fur, push the HOLD button up to unlock the comb, and push it forward repeatedly until the fur is sucked into the dust cup



**When the fur Deshedding brush is not in use, it is recommended to adjust the HOLD button to the unlocked state for easy storage.*

4. Crevice tool


Can be used to clean fur, small objects and dust in the corners of carpets and sofas



04 MAINTENANCE & CLEANING

1. Dust cup cleaning

- 1 Press the PUSH button and wait for the dust cup to lift up slightly to remove the dust cup



- 2 After opening the dust cup lid, remove the fur and clean the dust cup




- 3 Align the dust cup buckle with the slot of the main device, and then press the end of the dust cup. After heard a "click" sound, the installation is successful




2. Electric clipper cleaning

- 1 Push out the blade on the front side of the trimmer in the arrow direction




- 2 Turn on the device, use the hose to suck off the residual hair on the body fur trimmer, body fur clipper holder, Paw trimmer and electric clipper main body



Electric clipper body cannot be washed


(The above picture takes the body fur trimmer blade as an example, and the cleaning method of other parts is the same.)

- ③ Insert the bottom point **D** of the clipper blade into the groove point **E** of the clipper holder (as shown in the picture), press the clipper blade until heard a "click" sound, then the installation is successful




3. Filter cotton cleaning

- ① Turn off power supply, remove dust cup and filter cotton




- ② Rinse the filter cotton in cold water and gently wring it out



- ③ Place in a ventilated place to dry for more than 24 hours until completely dry



- ④ Place the dried filter cotton back on the dust cup




Note:


- * The filter cotton should be washed regularly with cold water
- * Depending on usage frequency, the maintenance period also differs, please clean regularly
- * When cleaning, remember to turn off the power and unplug the plug from the socket
- * Be sure to install the filter cotton after it is dry, filter cotton that is not dried will cause electric shock and device malfunction.

4. Hepa filter screen cleaning


❶ Turn off the power, take out the dust cup and the Hepa filter screen



❷ Rinse the Hepa filter screen with cold water and dry it after washing





❸ place in a well ventilated area to dry for over 24 hours until completely dry



❹ Install the dried Hepa filter screen back

Note: the front is facing outward (the lettering is on the front)



Note:

- Hepa filter screen shall be cleaned with cold water at least once a month.
- It is recommended to replace the Hepa filter screen if the suction is insufficient.
- The maintenance period varies according to the frequency and condition of use. Please clean it regularly.
- Please be sure to cut off the power and unplug it when cleaning.
- Please be sure to install the Hepa filter screen after drying. Use wet Hepa filter screen may cause electric shock and device failure.

05 BASIC SPECIFICATIONS

1. Main device parameters

Product name:	PET GROOMING KIT (PETKIT AIRCLIPPER 5-in-1)
Product model:	LM4
Main device dimensions:	309 *220 *140mm
Recommended pet types:	cats and dogs aged 6 months and above
Product material:	ABS
Total weight:	approx. 3.15kg
Soft hose length:	1.5m
Dust cup capacity:	1.4L
Power cable length:	2.5m
Maximum noise:	75dBA

2. Electric clipper parameters

Input:	DC 5V 1A
Power rating:	5W
Charge time:	approx. 3 hours
Operational duration:	approx. 2.5 hours
Lithium battery:	3.7V 1400mAh

06 A MESSAGE TO OUR VALUED CUSTOMERS

- Thank you for purchasing PET GROOMING KIT (PETKIT AIRCLIPPER 5-in-1). We at PETKIT have done our best to make life easier for you and your pets with technology.
- Please carefully read the User Manual before using the product. By setting up and using this product, you are acknowledged that you have already read and accepted the safety guidelines listed below.
- We are not liable and will not accept responsibility for any accidents or injuries that result from improper use of this product.
- PETKIT reserves the rights of interpretation and revision.

07 USER SAFETY GUIDE

* Failure to follow the safety guides outlined below result in product malfunction, or other accidental losses.

- This device is only suitable for indoor use in a dry environment, do not use it on wet ground.
- Please place the device on a hard and flat surface for use, and do not place on a soft and uneven object to prevent the device from falling.
- Do not use or store this product in damp places such as outdoors or bathrooms.
- It is forbidden to suck in wet hair and liquid, so as not to cause device short circuit.
- The device is to be used on cats and dogs over 6 months old.
- Minors are prohibited from using this device.
- Do not operate with wet hands or unplug the power cord to avoid malfunction and electric shock.
- Before use, please make sure the air inlet is not blocked.
- It is forbidden to use this product in areas with flammable liquids or combustibles, and do not suck in highly flammable items (such as cigarette butts, etc.), so as not to cause fire or explosion.
- The product may have a strange smell during first time use, but it will not cause any adverse effects on your pet, and the smell will disappear after a period of time, thank you for your understanding.
- If the device has a persistent burnt smell, stop use immediately!
- Please clean the dust cup and filter cotton regularly to avoid excessive dirt buildup and device malfunction.
- During maintenance and cleaning, please make sure that the power cord is removed.
- If the device temperature rises abnormally during use, please stop use immediately.
- Do not pinch or pull the power cord, and do not place heavy objects on top of the device.
- If the device motor heats up abnormally or the air inlet is blocked, please stop use immediately, take out the dust cup, make sure the air inlet and filter cotton are clean, and turn on the device after 60 minutes.
- Before use, please ensure that the filter cotton and filter screen have been installed to avoid damage to the motor.
- Pets biting the electrical wire will cause electric leakage, please ensure pet safety.
- For prolonged storage, please switch off the power first and then unplug the power cord.
- Please do not place it in direct sunlight and keep it away from ignition sources.
- Please do not use this product if the power cord or power plug is damaged.
- Do not soak this product in water.
- Do not stack items on top of the device.
- Please use the provided power cord, otherwise it will damage the equipment or cause potential safety hazards.
- Do not disassemble the equipment without authorization, and must be repaired under the guidance of professionals to avoid accidental injuries.
- If you encounter any problems while using this product, please contact us immediately.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and ;
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC warning

• English:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

• French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Disposal

The European directive 2012 / 19 / CE on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.